

Karta danych technicznych :

EMA II 20 HD-1



 **MANITOU**
HANDLING YOUR WORLD

The technical drawing consists of two views of a forklift:

- Top View (Left):** Shows the forklift from above. Dimensions include:
 - b_1 : Overall width of the chassis.
 - b_3 : Width of the mast base.
 - b : Overall width of the mast and forks.
 - l : Length of the chassis.
- Side View (Right):** Shows the forklift from the side. Dimensions include:
 - a : Height of the mast tip.
 - b : Horizontal distance from the mast tip to the rear axle.
 - c : Horizontal distance from the mast base to the front axle.
 - d : Horizontal distance from the mast base to the rear axle.
 - e : Horizontal distance from the mast base to the front wheel center.
 - f : Horizontal distance from the mast base to the rear wheel center.
 - g : Horizontal distance from the mast base to the rear wheel center (labeled as f in the diagram).
 - h_1 : Height of the operator's seat.
 - h_2 : Height of the mast base.
 - h_3 : Height of the mast.
 - h_4 : Total height of the mast tip.
 - h_5 : Height of the operator's seat.
 - h_6 : Height of the mast base.
 - h_7 : Height of the mast.
 - h_8 : Total height of the mast tip.
 - h_9 : Height of the operator's seat.
 - h_{10} : Height of the mast base.
 - h_{11} : Height of the mast.
 - h_{12} : Total height of the mast tip.
 - h_{13} : Height of the operator's seat.
 - h_{14} : Height of the mast base.
 - h_{15} : Height of the mast.
 - h_{16} : Total height of the mast tip.
 - h_{17} : Height of the operator's seat.
 - h_{18} : Height of the mast base.
 - h_{19} : Height of the mast.
 - h_{20} : Total height of the mast tip.
 - h_{21} : Height of the operator's seat.
 - h_{22} : Height of the mast base.
 - h_{23} : Height of the mast.
 - h_{24} : Total height of the mast tip.
 - h_{25} : Height of the operator's seat.
 - h_{26} : Height of the mast base.
 - h_{27} : Height of the mast.
 - h_{28} : Total height of the mast tip.
 - h_{29} : Height of the operator's seat.
 - h_{30} : Height of the mast base.
 - h_{31} : Height of the mast.
 - h_{32} : Total height of the mast tip.
 - h_{33} : Height of the operator's seat.
 - h_{34} : Height of the mast base.
 - h_{35} : Height of the mast.
 - h_{36} : Total height of the mast tip.
 - h_{37} : Height of the operator's seat.
 - h_{38} : Height of the mast base.
 - h_{39} : Height of the mast.
 - h_{40} : Total height of the mast tip.
 - h_{41} : Height of the operator's seat.
 - h_{42} : Height of the mast base.
 - h_{43} : Height of the mast.
 - h_{44} : Total height of the mast tip.
 - h_{45} : Height of the operator's seat.
 - h_{46} : Height of the mast base.
 - h_{47} : Height of the mast.
 - h_{48} : Total height of the mast tip.
 - h_{49} : Height of the operator's seat.
 - h_{50} : Height of the mast base.
 - h_{51} : Height of the mast.
 - h_{52} : Total height of the mast tip.
 - h_{53} : Height of the operator's seat.
 - h_{54} : Height of the mast base.
 - h_{55} : Height of the mast.
 - h_{56} : Total height of the mast tip.
 - h_{57} : Height of the operator's seat.
 - h_{58} : Height of the mast base.
 - h_{59} : Height of the mast.
 - h_{60} : Total height of the mast tip.
 - h_{61} : Height of the operator's seat.
 - h_{62} : Height of the mast base.
 - h_{63} : Height of the mast.
 - h_{64} : Total height of the mast tip.
 - h_{65} : Height of the operator's seat.
 - h_{66} : Height of the mast base.
 - h_{67} : Height of the mast.
 - h_{68} : Total height of the mast tip.
 - h_{69} : Height of the operator's seat.
 - h_{70} : Height of the mast base.
 - h_{71} : Height of the mast.
 - h_{72} : Total height of the mast tip.
 - h_{73} : Height of the operator's seat.
 - h_{74} : Height of the mast base.
 - h_{75} : Height of the mast.
 - h_{76} : Total height of the mast tip.
 - h_{77} : Height of the operator's seat.
 - h_{78} : Height of the mast base.
 - h_{79} : Height of the mast.
 - h_{80} : Total height of the mast tip.
 - h_{81} : Height of the operator's seat.
 - h_{82} : Height of the mast base.
 - h_{83} : Height of the mast.
 - h_{84} : Total height of the mast tip.
 - h_{85} : Height of the operator's seat.
 - h_{86} : Height of the mast base.
 - h_{87} : Height of the mast.
 - h_{88} : Total height of the mast tip.
 - h_{89} : Height of the operator's seat.
 - h_{90} : Height of the mast base.
 - h_{91} : Height of the mast.
 - h_{92} : Total height of the mast tip.
 - h_{93} : Height of the operator's seat.
 - h_{94} : Height of the mast base.
 - h_{95} : Height of the mast.
 - h_{96} : Total height of the mast tip.
 - h_{97} : Height of the operator's seat.
 - h_{98} : Height of the mast base.
 - h_{99} : Height of the mast.
 - h_{100} : Total height of the mast tip.

Dane techniczne masztów i udźwig bezpieczny

Maszt potrójny z wolnym skokiem (FLT)		FLT 56	FLT 60	FLT 66	FLT 70	FLT 76	FLT 80	FLT 86	FLT 90	FLT 95	FLT 102	FLT 106
α - Pochył masztu/widel karetki przód	°	1	1	1	1	1	1	1	1	1	1	1
β - Pochył masztu/widel karetki tył	°	3	3	3	3	3	3	3	3	3	3	3
h1 - Wysokość złożonego masztu	mm	2750	2900	3150	3290	3590	3720	4020	4150	4500	4690	4820
h2 - Wolny skok	mm	1930	2080	2330	2470	2770	2900	3200	3330	3650	3870	4000
h3 - Wysokość podnoszenia	mm	5550	6000	6600	7020	7620	8010	8610	9000	9500	10200	10560
h4 - Wysokość wysuniętego masztu	mm	6380	6830	7430	7850	8450	8840	9440	9830	10475	11175	11535
Udźwig ze zintegrowanym przesuwem bocznym (przemysłowa tabela udźwигów)	kg	1600	1450	1450	1300	1300	1200	1100	1000	900	750	650

**Siedziba główna**

B.P. 249 - 430 rue de l'Aubinière

44150 Ancenis Cedex - France

Tel: +33 (0)2 40 09 10 11 - Fax: +33 (0)2 40 09 10 97

www.manitou.com

Niniejsza publikacja opisuje wersje i możliwości konfiguracji produktów Manitou, które mogą różnić się wyposażeniem. Wyposażenie przedstawione w niniejszej broszurze może być standardowe, opcjonalne lub niedostępne w zależności od wersji. Manitou zastrzega sobie prawo do zmiany opisanych i przedstawionych specyfikacji w dowolnym momencie bez uprzedzenia. Przedstawione specyfikacje nie są wiążące dla producenta. Aby uzyskać więcej szczegółów, należy skontaktować się z dealerem Manitou. Dokument niebędący umową. Prezentacja i wizualizacje produktów nie są umowne. Loga i identyfikacja wizualna firmy są własnością Manitou i nie mogą być wykorzystywane bez zgody. Wszelkie prawa zastrzeżone. Zdjęcia i schematy zawarte w niniejszej broszurze służą wyłącznie celom poglądowym.

Manitou BF SA - Spółka akcyjna z Radą Dyrektorów - Kapitał zakładowy: 39 668 399 euro - 857 802 508 RCS Nantes