Technical sheet :

MHT-X 11250 MINING







MHT-X 11250 MINING Created on September 9, 2025 at 9:41 PM UTC

Capacities	Metric
Max. capacity	24999 kg
Load center of gravity	c 900 mm
Max. lifting height	10.60 m
Maximum outreach	6 m
Weight and dimensions	
Overall length	l1 8.92 m
Unladen weight (with forks)	31610 kg
Ground clearance	m4 0.47 m
Wheelbase	y 4.10 m
Length to face of forks	l2 7.12 m
Overall width	b1 2.84 m
Overall height	h17 3.03 m
Overall cab width	b4 0.95 m
Tilt-up angle	a4 12 °
Tilt-down angle	a5 105 °
External turning radius (over tyres)	Wa1 5.50 m
Forks length / width / section	l / e / s 1800 mm x 220 mm x 100 mm
Frame leveling corrector	a9 10 °
Wheels	
Standard tires	18.00 R25
Number of front wheels / rear wheels	2/2
Drive wheels (front / rear)	2/2
Steering mode	2 wheel steer, 4 wheel steer, Crab mode
Engine	
Engine brand	Yanmar
Engine norm	Stage IIIA
Engine model	4TN107TT-6SMU2
Number of cylinders / Capacity of cylinders	4 - 4567 cm ³
I.C. Engine power rating / Power	211 Hp / 155 kW
Max. torque / Engine rotation	805 Nm@1500 rpm
Engine cooling system	Water
Number of batteries	2
Battery voltage	12 V
Transmission	12 V
Transmission type	Hydrostatic
Number of gears (forward / reverse)	2/2
Max. travel speed	2 / 2 25 km/h
	Automatic negative parking brake
Parking brake	Oil-immersed multi-discs braking on front &
Service brake	oli-immersed multi-discs braking on front & axles
Gradeability (laden / unladen)	57.70 % / 31.50 %
Hydraulics	
Hydraulic pump type	Variable displacement pump
Hydraulic flow - Pressure	275 l/min - 350 bar
Tank capacities	
Engine oil	131
Fuel tank	315
Miscellaneous	
Cab certification	Cabin ROPS - FOPS level 2
Controls	JSM


MHT-X 11250 Mining - Dimensional drawing









MHT-X 11250 Mining - Load chart




Machine on tires with winch 25000 kg (Metric)



Machine on tires with forks LC 1200 mm Metric





Machine on tires with 3-hook jib 25000 kg (Metric)




Machine on tires with underground mining platform (Metric)

Machine on tires with tire handler TH 63 (Metric)





Machine on tires with cylinder handler CH 10 (Metric)



Mining Specifications

Lifting functionSCamere in boom head with screen in cabSClamp predisposition (controls from cabin)SWorking platform predisposition with remote controlSLightingBrake Lights ON When Park Brake ONSFlat Led Rotating BeaconSLED Flashing Lights On Cabin (Marker Lights)SLED Flashing Lights On Cabin (Marker Lights)SLED tranming lightsSLED working lights - On the top of the boom (fixed part) (x2)SLED working lights on cab (x4 : 2 front + 2 rear)SMotorization/PowerSExhaust 1 ume purification systemSHydraulic hose sleeve burst protectionSRadiator safety capSOperator stationSOperator stationSOther optionsSBattery + Starter Isolators + Jump Start ReceptacleSPneumaticsSSteel mudguadsOSecondary functionsSAutomatic greasing system (AGS) - Chassis + boomOFast fuel filling systemSBoom cylinder lockSElectromagnetic braking system TELMAOEmergency stop is a fely valveOEmergency stop is no bay 2, on externalSLing using abstem file prevention kitOEmergency stop is no bay 2, on externalSBoom cylinder lockSElectromagnetic braking system TELMAOEmergency stop is no bay 2, on externalSLing using abstem file in du back windowsO		MHT-X 11250 Mining
Clamp predisposition (controls from cabin)SUnder predisposition with remote controlSLightingSBrake Lights ON When Park Brake ONSFlat Led Rotating BeaconSLED Flashing Lights On Cabin (Marker Lights)SLED working lightsSLED working lights on cab (x4 : 2 front + 2 rear)SMotorization/PowerSExhaust Tume purification systemSHydraulic hose sleeve burst protectionSRadiator safety capSOperator stationSCabin first step at 400 mmSRoof and Windshield GuardSOther optionsSBattery + Starter Isolators + Jump Start ReceptacleSPneumaticsSSteel IndiguardsOSecondary functionsSSecondary functionsS<	Lifting function	
Working platform predisposition with remote controlSLights ON When Park Brake ONSBrake Lights ON When Park Brake ONSFlat Led Rotating BeaconSLED Flashing Lights On Cabin (Marker Lights)SLED tramming lightsSLED tramming lights on cab (x4 : 2 front + 2 rear)SModorization/PowerEExhaust fume purification systemSHydraulic hose sleeve burst protectionSRadiator safety capSOperator stationSCabin first step at 400 mmSRoof and Windshield GuardSOther optionsSBattery + Stater Isolators + Jump Statt ReceptacleSPneumaticsSSteel mudguardsOSecondary functionsSSteel mudguardsOSecondary functionsSSteel mudguardsSSoor sylinder lockSElectromagnetic braking system LEMAOSoor sylinder lockSElectromagnetic braking system TELMAOEmergency step in cab, 2 on externalSEngine compartment fire prevention kitOExtinguisher brackets (x3)SFire suppression systemSHigh visibility seflective stripsSLoose wheel nut indicatorsSMarking - Varting & Danger decalsSMining protection right, left and back windowsNNogative brakes on front & Rar AlesSRear and lateral camera with cab screenS	Camera in boom head with screen in cab	S
LightingBrake Lights ON When Park Brake ONSFlat Led Rotating BeaconSLED Flashing Lights On Cabin (Marker Lights)SLED tramming lightsSLED tramming lightsSLED working lights on cab (x4 : 2 front + 2 rear)SMotoration/PowerSExhaust fume purification systemSHydraulic hose sleeve burst protectionSRadiator safety capSOperator stationSCabin first step at 400 mmSRoof and Windshield GuardSOther optionsSBattery + Starter Isolators + Jump Start ReceptacleSPheumaticsOSecondary functionsOSecondary functionsOSecondary functionsSAutomatic greasing system (AGS) - Chassis + boomOFast fuel filling systemSBotter poly by safety systemSBoom cylinder lockSElectromagnetic braking system TELMAOEmergency stop by safety valveOEmergency stop by safety valveOEmergency stop by safety valveSEngine compartment fire prevention kitOEngine compartment fire prevention kitSLing systemSLing system SSLing system SSLing system SSLing sologi right, left and back windowsSNotificatorsSMing protection rights: right, left and back windowsSNaring vanning & Danger decals	Clamp predisposition (controls from cabin)	S
Brake Lights ON When Park Brake ONSFlat Led Rotating BeaconSLED Flashing Lights On Cabin (Marker Lights)SLED tramming lightsSLED work lights - On the top of the boom (fixed part) (x2)SLED work lights - On the top of the boom (fixed part) (x2)SLED work lights on cab (x4 : 2 front + 2 rear)SMotorZation/PowerSExhaust fume purification systemSHydraulic hose sleeve burst protectionSRadiator safety capSOperator stationSCabin first step at 400 mmSRoof and Windshield GuardSOther optionsSBattery + Starter Isolators + Jump Start ReceptacleSPneumaticsSSteel mudguardsOSeconday functionsOAutomatic greasing system (AGS) - Chassis + boomOFast fuel filling systemSBoom cylinder lockSElectromagnetic braking system TELMAOEmergency steeringSEnergency steeringSEngine compartment fire prevention kitOEntiguisher brackets (x3)SFire suppression systemSHigh visibility reflective stripsSLoose wheel nut indicatorsSMarking - Warning & Danger decalsSMining protection grids: right, left and back windowsSNotaring & SemeSEnergency step ing ing here analesSHigh visibility reflective stripsSLoose wheel	Working platform predisposition with remote control	S
Flat Led Notaling BeaconSLED Flashing Lights On Cabin (Marker Lights)SLED tranming lightsSLED working lights on the top of the boom (fixed part) (x2)SLED working lights on cab (x4 : 2 front + 2 rear)SMotorization/PowerSExhaust fume putification systemSHydraulic hose sleeve burst protectionSRadiator safety capSOperator stationSCabin first step at 400 mmSRoof and Windshield GuardSOther optionsSBattery + Stater Isolators + Jump Start ReceptacleSPneumaticsOSecondary functionsOSecondary functionsOSecondary functionsSGuardian Angel" System Level 1SS60" visibility safety systemSBoon cylinder lockSElectromagnetic braking system TELMAOEmergency step ingSEmergency step ingSEngregory step ing in tab, 2 on externalSEngregory step ing in tab, 2 on externalSEngregory step ing in tab, 2 on externalSEngregory step ing	Lighting	
LED Flashing Lights On Cabin (Marker Lights)SLED tramming lightsSLED work lights - On the top of the boom (fixed part) (x2)SLED work lights on cab (x4 : 2 front + 2 rear)SMotorization/PowerSExhaust fume purification systemSHydraulic hose sleeve burst protectionSRadiator safety capSOperator stationSCabin first step at 400 mmSRoof and Windshield GuardSOther optionsSBattery + Starter Isolators + Jump Start ReceptacleSPneumaticsUSteel mudguardsOSecondary functionsSAutomatic greasing system (AGS) - Chassis + boomOFast fuel filling systemOSecurityS"Guardian Angel" system Level 1SSofo" wisibility safety systemSBoom cylinder lockSElectromagnetic braking system TELMAOEmergency stop by safety valveSEngine compartment fire prevention kitSEritiguisher brackets (x3)SFire suppression systemOFire suppression systemSLoose wheel nut indicatorsSMaking - Waning & Danger decalsSMoting yottection right: right, left and back windowsONegative brakes on front & rear axlesSRear bumperOSteel Protection file surfices on all working and road lightsSSteel protection on all working and road lightsS	Brake Lights ON When Park Brake ON	S
LED tramming lightsSLED work lights - On the top of the boom (fixed part) (x2)SLED working lights on cab (x4 : 2 front + 2 rear)SMotofization/PowerSExhaust fume purification systemSHydraulic hose sleeve burst protectionSRadiator safety capSOperator stationSCabin first step at 400 mmSRoof and Windshield GuardSOther optionsSBattery + Starter Isolators + Jump Start ReceptacleSPheumaticsOSteel mudguardsOSecondary functionsOAutomatic greasing system (AGS) - Chassis + boomOFast fuel filling systemOSecondary functionsSAutomatic greasing system (AGS) - Chassis + boomOFast fuel filling systemSBoom cylinder lockSElectromagnetic braking system TELMAOEmergency stop by safety valveOEmergency stop by safety valveOEmergency stop by safety valveOEnergency stop by safety valveSFire suppression systemOFire suppression systemOFire suppression systemSLoose wheel nut indicatorsSMarking - Waning & Danger decalsSMining protection rids: right, left and back windowsONegative brakes on front & rear axlesSRear dumperORear bumperORear bumperORear bumperO </td <td>Flat Led Rotating Beacon</td> <td>S</td>	Flat Led Rotating Beacon	S
LED work lights - On the top of the boom (fixed part) (x2)SLED working lights on cab (x4 : 2 front + 2 rear)SMotofization/PowerSExhaust fume purification systemSHydraulic hose sleeve burst protectionSRadiator safety capSOperator stationSCabin first step at 400 mmSRoof and Windshield GuardSOther optionsSBattery + Statter Isolators + Jump Start ReceptacleSPneumaticsOSecondary functionsOAutomatic greasing system (AGS) - Chassis + boomOFast fuel filling systemOSecondary functionsSAutomatic greasing system (AGS) - Chassis + boomOFast fuel filling systemSGoor visibility safety systemSBoom cylinder lockSElectromagnetic braking system TELMAOEmergency steeringSEingine compartment fire prevention kitOExtinguisher brackets (x3)SFire suppression systemOFurs suppression systemSLoose wheel nut indicatorsSMarking - Warning & Danger decalsSMarking - Warning & Danger decalsSMarking - Warning & Danger decalsSRear al lateral camera with cab screenSRear al lateral camera with cab screenSRear bumperOSteel Protection Guards on all working and road lightsSSystem with attachments recognition (E-reco)S <td>LED Flashing Lights On Cabin (Marker Lights)</td> <td>S</td>	LED Flashing Lights On Cabin (Marker Lights)	S
LED working lights on cab (x4 : 2 front + 2 rear)SMotofization/PowerSExhaust fume purification systemSHydraulic hose sleeve burst protectionSRadiator safety capSOperator stationSCabin first step at 400 mmSRoof and Windshield GuardSOther optionsSBattery + Starter Isolators + Jump Start ReceptacleSPneumaticsOSteel mudguardsOSecondary functionsOAutomatic greasing system (AGS) - Chassis + boomOFast fuel filling systemOSecurityS"Guardian Angel" System Level 1SSoft visibility afety systemSBoom cylinder lockSElectromagnetic braking system TELMAOEmergency steeringSEmergency steeringSEingine compartment fire prevention kitOExtinguisher brackets (x3)SFire suppression systemSHigh visibility reflective stripsSLoose wheel nut indicatorsSMarking - Warning & Danger decalsSMarking - Warning & Danger decalsSMarking - Warning & Danger decalsSRear al lateral camera with cab screenSRear al lateral camera with cab screenSRear bumperOSystem with attachments recognition (E-reco)S	LED tramming lights	S
Motorization/PowerSExhaust fume purification systemSHydraulic hose sleeve burst protectionSRadiator safety capSOperator stationSCabin first step at 400 mmSRoof and Windshield GuardSOther optionsSBattery + Starter Isolators + Jump Start ReceptacleSPneumaticsOSteel mudguardsOSecondary functionsOAutomatic greasing system (AGS) - Chassis + boomOFast fuel filling systemOSecurityO"Guardian Angel" System Level 1S360" visibility safety systemSBoom cylinder lockSElectromagnetic braking system TELMAOEmergency step ingSEmergency stop is afety valveOEntregency stop is afety valveOEntregency stop systemSLoose wheel nut indicatorsSMarking - Waming & Danger decalsSMarking - Waming & Danger decalsSMarking - Waming & Danger decalsSMarking - Waming & Danger decalsSRear and lateral camera with cab screenSRear bumperOSteel Protection Guards on all working and road lightsSSystem with attachments recognition (Ereco)S	LED work lights - On the top of the boom (fixed part) (x2)	S
Exhaust fume purification systemSHydraulic hose sleeve burst protectionSRadiator safety capSOperator stationSCabin first step at 400 mmSRoof and Windshield GuardSOther optionsSBattery + Stater Isolators + Jump Start ReceptacleSPheumaticsOSteel mudguardsOSecondary functionsOAutomatic greasing system (AGS) - Chassis + boomOFast fuel filling systemOSecurityO"Guardian Angel" System Level 1S360" visibility safety systemSBoom cylinder lockSEnergency stop in cab, 2 on externalSEnergency stop in cab, 2 on externalSEngine compartment fire prevention kitOExtinguisher brackets (x3)SFire suppression systemSHigh visibility reflective stripsSLoose wheel nut indicatorsSMarking - Waming & Danger decalsSMarking - Waming & Danger decalsSRear and lateral camera with cab screenSRear and lateral camera with cab screenSRear bumperOSteel Protection Guards on all working and road lightsSSystem with attachments recognition (E-reco)S	LED working lights on cab (x4 : 2 front + 2 rear)	S
Hydraulic hose sleeve burst protectionSRadiator safety capSOperator stationSCabin first step at 400 mmSRoof and Windshield GuardSOther optionsSBattery + Starter Isolators + Jump Start ReceptacleSPheumatics0Steel mudguards0Secondary functions0Automatic greasing system (AGS) - Chassis + boom0Fast fuel filling system0Secundary functions0Secundary functions0Automatic greasing system (AGS) - Chassis + boom0Fast fuel filling system0Secundary functions0Secundary functions0Automatic greasing system (AGS) - Chassis + boom0Fast fuel filling system0Secundary functions0Secundary functionsSAutomatic greasing system TELMA0Boom cylinder lockSElectromagnetic braking system TELMA0Emergency stop: 1 in cab, 2 on externalSEngine compartment fire prevention kit0Engine compartment fire prevention kit0Extinguisher brackets (x3)SFire suppression system0Fuse badd protection - MHT'sSHigh visibility reflective stripsSLoose wheel nut indicatorsSMarking - Waming & Danger decalsSMining protection grids: right, left and back windows0Negative brakes on front & rear axlesSRe	Motorization/Power	
Radiator safety capSOperator stationSCabin first step at 400 mmSRoof and Windshield GuardSOther optionsSBatter + Statter Isolators + Jump Start ReceptacleSPneumaticsOSteel mudguardsOSecondary functionsOAutomatic greasing system (AGS) - Chassis + boomOFast fuel filling systemOSecondary functionsOSecondary functionsSSecondary functionsSSecondary functionsSSecondary functionsSSecondary functionsSSecondary functionsSSecondary functionsSBoom cylinder lockSElectromagnetic braking system TELMAOEmergency steep by safety valveOEmergency steep ing in cab, 2 on externalSEngine compartment fire prevention kitOEngine compartment fire prevention kitOEngine compartment fire prevention kitOFire suppression systemSLoose wheel nut indicatorsSMarking - Warning & Dan	Exhaust fume purification system	S
Operator stationCabin first step at 400 mmSRoof and Windshield GuardSOther optionsSBattery + Starter Isolators + Jump Start ReceptacleSPneumaticsOSteel mudguardsOSecondary functionsOAutomatic greasing system (AGS) - Chassis + boomOFast fuel filling systemOSecurityO"Guardian Angel" System Level 1S360° visibility safety systemSBoom cylinder lockSElectromagnetic braking system TELMAOEmergency step by safety valveOEmergency step in cab, 2 on externalSEngine compartment fire prevention kitOExtinguisher brackets (x3)SFire suppression systemOFuse board protection - MHTSSHigh visibility reflective stripsSLoose wheel nut indicatorsSMarking - Warning & Danger decalsSMining protection gids: right, left and back windowsONegative brakes on front & rear axlesSRear and lateral camera with cab screenSRear and lateral camera with cab screenSRear DumperOSteel Protection Guards on all working and road lightsSSystem with attachments recognition (E-reco)S	Hydraulic hose sleeve burst protection	S
Cabin first step at 400 mmSRoof and Windshield GuardSOther optionsSBattery + Starter Isolators + Jump Start ReceptacleSPneumaticsOSteel mudguardsOSecondary functionsOAutomatic greasing system (AGS) - Chassis + boomOFast fuel filling systemOSecurityS"Guardian Angel" System Level 1S360° visibility safety systemSBoom cylinder lockSElectromagnetic braking system TELMAOEmergency step in cab, 2 on externalSEngine compartment fire prevention kitOExtinguisher brackets (x3)SFire suppression systemOFuse board protection - MHT'sSLoose wheel nut indicatorsSMarking - Waming & Danger decalsSMining protection guids: right, left and back windowsONegative brakes on front & ear axlesSRear and lateral camera with cab screenSRear and lateral camera with cab screenSRear bumperOSteel Protection Guards on all working and road lightsSSystem with attachments recognition (Ereco)S	Radiator safety cap	S
Roof and Windshield GuardSOther optionsSBattery + Statter Isolators + Jump Start ReceptacleSPheumaticsOSteel mudguardsOSecondary functionsOAutomatic greasing system (AGS) - Chassis + boomOFast fuel filling systemOSecurityO"Guardian Angel" System Level 1S360° visibility safety systemSBoom cylinder lockSElectromagnetic braking system TELMAOEmergency stepingSEmergency stop by safety valveOEmergency stop: 1 in cab, 2 on externalSEngine compartment fire prevention kitOExtinguisher brackets (x3)SFire suppression systemOFuse board protection - MHT'sSLoose wheel nut indicatorsSMarking - Waming & Danger decalsSMining protection grids: right, left and back windowsONegative brakes on front & tera axlesSRear and lateral camera with cab screenSRear and lateral camera with cab screenSRear bumperOSteel Protection Guards on all working and road lightsSSystem with attachments recognition (E-reco)S		
Roof and Windshield GuardSOther optionsSBattery + Starter Isolators + Jump Start ReceptacleSPheumaticsOSteel mudguardsOSecondary functionsOAutomatic greasing system (AGS) - Chassis + boomOFast fuel filling systemOSecurityO"Guardian Angel" System Level 1S360° visibility safety systemSBoom cylinder lockSElectromagnetic braking system TELMAOEmergency stepingSEnergency stop by safety valveOEmergency stop: 1 in cab, 2 on externalSEngine compartment fire prevention kitOExtinguisher brackets (x3)SFire suppression systemOFuse board protection - MHT'sSLoose wheel nut indicatorsSMarking - Waming & Danger decalsSMining protection grids: right, left and back windowsONing rotection Guards on all working and road lightsSSystem with attachments recognition (Ereco)S	Cabin first step at 400 mm	S
Battery + Starter Isolators + Jump Start ReceptacleSPneumatics0Steel mudguards0Secondary functions0Automatic greasing system (AGS) - Chassis + boom0Fast fuel filling system0Security0"Guardian Angel" System Level 1S360° visibility safety systemSBoom cylinder lockSElectromagnetic braking system TELMA0Emergency steringSEmergency steringSEmergency stop is a fety valve0Emergency stop is no 2, on externalSEngine compartment fire prevention kit0Extinguisher brackets (x3)SFire suppression system0Fuse board protection - MHT'sSHigh visibility reflective stripsSLoose wheel nut indicatorsSMarking - Warning & Danger decalsSRear and lateral camera with cab screenSRear and lateral camera with cab screenSRear bumper0System with attachments recognition (E-reco)S	Roof and Windshield Guard	S
PheumaticsSteel mudguards0Secondary functions0Automatic greasing system (AGS) - Chassis + boom0Fast fuel filling system0Security0"Guardian Angel" System Level 1S360° visibility safety systemSBoom cylinder lockSElectromagnetic braking system TELMA0Emergency steeringSEmergency steeringSEmergency step by safety valve0Emergency step in in cab, 2 on externalSEngine compartment fire prevention kit0Extinguisher brackets (x3)SFire suppression system0Fuse board protection - MHT'sSLoose wheel nut indicatorsSMarking - Warning & Danger decalsSMarking - Warning & Danger decalsSRear and lateral camera with cab screenSRear bumper0Steel Protection Guards on all working and road lightsSSystem with attachments recognition (E-reco)S	Other options	
PneumaticsSteel mudguards0Secondary functions0Automatic greasing system (AGS) - Chassis + boom0Fast fuel filling system0Security0"Guardian Angel" System Level 1S360° visibility safety systemSBoom cylinder lockSElectromagnetic braking system TELMA0Emergency steeringSEmergency stept yalve0Emergency stop 1 in cab, 2 on externalSEngine compartment fire prevention kit0Extinguisher brackets (x3)SFire suppression systemSLoose wheel nut indicatorsSMarking - Warning & Danger decalsSMarking - Warning & Danger decalsSRear and lateral camera with cab screenSRear bumper0Steel Protection Guards on all working and road lightsSSystem with attachments recognition (E-reco)S	Battery + Starter Isolators + Jump Start Receptacle	S
Secondary functionsAutomatic greasing system (AGS) - Chassis + boom0Fast fuel filling system0Security0"Guardian Angel" System Level 1S360° visibility safety systemSBoom cylinder lockSElectromagnetic braking system TELMA0Emergency steeringSEmergency stept yalve0Emergency stop by safety valve0Emergency stop: 1 in cab, 2 on externalSEngine compartment fire prevention kit0Extinguisher brackets (x3)SFire suppression system0Fuse board protection - MHT'sSLoose wheel nut indicatorsSMarking - Warning & Danger decalsSMarking - Warning & Strept and screenSRear and lateral camera with cab screenSRear bumper0Steel Protection Guards on all working and road lightsSSystem with attachments recognition (E-reco)S		
Automatic greasing system (AGS) - Chassis + boom0Fast fuel filling system0Security0"Guardian Angel" System Level 1S360° visibility safety systemSBoom cylinder lockSElectromagnetic braking system TELMA0Emergency steeringSEmergency stop by safety valve0Emergency stop: 1 in cab, 2 on externalSEngine compartment fire prevention kit0Extinguisher brackets (x3)SFire suppression system00Fuse board protection - MHT'sSHigh visibility reflective stripsSLoose wheel nut indicatorsSMining protection guars: right, left and back windows0Negative brakes on front & rear axlesSRear bumper0Rear bumper0Steel Protection Guards on all working and road lightsSSystem with attachments recognition (E-reco)S		0
Fast fuel filling system0Security0"Guardian Angel" System Level 1S360° visibility safety systemSBoom cylinder lockSElectromagnetic braking system TELMA0Emergency steeringSEmergency stept yalve0Emergency stop by safety valve0Emergency stop: 1 in cab, 2 on externalSEngine compartment fire prevention kit0Extinguisher brackets (x3)SFire suppression system0Fuse board protection - MHT'sSLoose wheel nut indicatorsSMining protection gids: right, left and back windows0Negative brakes on front & rear axlesSRear and lateral camera with cab screenSRear bumper0Steel Protection Guards on all working and road lightsSSystem with attachments recognition (E-reco)S	Secondary functions	
Fast fuel filling system0Security0"Guardian Angel" System Level 1S360° visibility safety systemSBoom cylinder lockSElectromagnetic braking system TELMA0Emergency steeringSEmergency stept yalve0Emergency stop by safety valve0Emergency stop: 1 in cab, 2 on externalSEngine compartment fire prevention kit0Extinguisher brackets (x3)SFire suppression system0Fuse board protection - MHT'sSLoose wheel nut indicatorsSMining protection gids: right, left and back windows0Negative brakes on front & rear axlesSRear and lateral camera with cab screenSRear bumper0Steel Protection Guards on all working and road lightsSSystem with attachments recognition (E-reco)S	Automatic greasing system (AGS) - Chassis + boom	0
Security"Guardian Angel" System Level 1S360° visibility safety systemSBoom cylinder lockSElectromagnetic braking system TELMAOEmergency steeringSEmergency steeringSEmergency stop by safety valveOEmergency stop: 1 in cab, 2 on externalSEngine compartment fire prevention kitOExtinguisher brackets (x3)SFire suppression systemOFuse board protection - MHT'sSHigh visibility reflective stripsSLoose wheel nut indicatorsSMarking - Warning & Danger decalsSMining protection gids: right, left and back windowsONegative brakes on front & rear axlesSRear bumperORear bumperORear bumperOSystem with attachments recognition (E-reco)S		0
360° visibility safety systemSBoom cylinder lockSElectromagnetic braking system TELMAOEmergency steeringSEmergency stop by safety valveOEmergency stop: 1 in cab, 2 on externalSEngine compartment fire prevention kitOExtinguisher brackets (x3)SFire suppression systemOFuse board protection - MHTsSHigh visibility reflective stripsSLoose wheel nut indicatorsSMarking - Waming & Danger decalsSMining protection gids: right, left and back windowsONegative brakes on front & rear axlesSRear and lateral camera with cab screenSRear bumperOSteel Protection Guards on all working and road lightsSSystem with attachments recognition (E-reco)S	Security	
Boom cylinder lockSElectromagnetic braking system TELMA0Emergency steeringSEmergency stop by safety valve0Emergency stop: 1 in cab, 2 on externalSEngine compartment fire prevention kit0Extinguisher brackets (x3)SFire suppression system0Fuse board protection - MHT'sSHigh visibility reflective stripsSLoose wheel nut indicatorsSMarking - Warning & Danger decalsSMining protection guards on find & rear axlesSRear and lateral camera with cab screenSRear bumper0Right side bumper0System with attachments recognition (E-reco)S	"Guardian Angel" System Level 1	S
Electronagnetic braking system TELMA0Emergency steeringSEmergency stop by safety valve0Emergency stop: 1 in cab, 2 on externalSEngine compartment fire prevention kit0Extinguisher brackets (x3)SFire suppression system0Fuse board protection - MHT'sSHigh visibility reflective stripsSLoose wheel nut indicatorsSMarking - Warning & Danger decalsSMining protection grids: right, left and back windows0Negative brakes on front & rear axlesSRear and lateral camera with cab screenSRear bumper0Steel Protection Guards on all working and road lightsSSystem with attachments recognition (E-reco)S	360° visibility safety system	S
Emergency steeringSEmergency stop by safety valveOEmergency stop: 1 in cab, 2 on externalSEngine compartment fire prevention kitOExtinguisher brackets (x3)SFire suppression systemOFuse board protection - MHTsSHigh visibility reflective stripsSLoose wheel nut indicatorsSMarking - Warning & Danger decalsSMining protection grids: right, left and back windowsONegative brakes on front & rear axlesSRear and lateral camera with cab screenSRear bumperOSteel Protection Guards on all working and road lightsSSystem with attachments recognition (E-reco)S	Boom cylinder lock	S
Emergency stop by safety valve0Emergency stop: 1 in cab, 2 on externalSEngine compartment fire prevention kit0Extinguisher brackets (x3)SFire suppression system0Fuse board protection - MHT'sSHigh visibility reflective stripsSLoose wheel nut indicatorsSMarking - Waming & Danger decalsSMining protection grids: right, left and back windows0Negative brakes on front & rear axlesSRear and lateral camera with cab screenSRear bumper0Steel Protection Guards on all working and road lightsSSystem with attachments recognition (E-reco)S	Electromagnetic braking system TELMA	0
Emergency stop: 1 in cab, 2 on externalSEngine compartment fire prevention kitOExtinguisher brackets (x3)SFire suppression systemOFuse board protection - MHT'sSHigh visibility reflective stripsSLoose wheel nut indicatorsSMarking - Waming & Danger decalsSMining protection grids: right, left and back windowsONegative brakes on front & rear axlesSRear and lateral camera with cab screenSRear bumperOSteel Protection Guards on all working and road lightsSSystem with attachments recognition (E-reco)S	Emergency steering	S
Engine compartment fire prevention kit0Extinguisher brackets (x3)SFire suppression system0Fuse board protection - MHTsSHigh visibility reflective stripsSLoose wheel nut indicatorsSMarking - Warning & Danger decalsSMining protection grids: right, left and back windows0Negative brakes on front & rear axlesSRear and lateral camera with cab screenSRear bumper0Right side bumper0Steel Protection Guards on all working and road lightsSSystem with attachments recognition (E-reco)S	Emergency stop by safety valve	0
Extinguisher brackets (x3)SFire suppression system0Fuse board protection - MHT'sSHigh visibility reflective stripsSLoose wheel nut indicatorsSMarking - Waming & Danger decalsSMarking - Waming & Danger decalsSMarking protection grids: right, left and back windows0Negative brakes on front & rear axlesSRear and lateral camera with cab screenSRear bumper0Right side bumper0Steel Protection Guards on all working and road lightsSSystem with attachments recognition (E-reco)S	Emergency stop: 1 in cab, 2 on external	S
Extinguisher brackets (x3)SFire suppression system0Fuse board protection - MHT'sSHigh visibility reflective stripsSLoose wheel nut indicatorsSMarking - Waming & Danger decalsSMarking - Waming & Danger decalsSMarking protection grids: right, left and back windows0Negative brakes on front & rear axlesSRear and lateral camera with cab screenSRear bumper0Right side bumper0Steel Protection Guards on all working and road lightsSSystem with attachments recognition (E-reco)S	Engine compartment fire prevention kit	0
Fire suppression system0Fuse board protection - MHTsSHigh visibility reflective stripsSLoose wheel nut indicatorsSMarking - Warning & Danger decalsSMining protection grids: right, left and back windows0Negative brakes on front & rear axlesSRear and lateral camera with cab screenSRear bumper0Right side bumper0Steel Protection Guards on all working and road lightsSSystem with attachments recognition (E-reco)S		S
Fuse baard protection - MHT'sSHigh visibility reflective stripsSLoose wheel nut indicatorsSMarking - Waming & Danger decalsSMining protection grids: right, left and back windowsONegative brakes on front & rear axlesSRear and lateral camera with cab screenSRear bumperORight side bumperOSteel Protection Guards on all working and road lightsSSystem with attachments recognition (E-reco)S	,	0
High visibility reflective stripsSLoose wheel nut indicatorsSMarking - Warning & Danger decalsSMining protection grids: right, left and back windowsONegative brakes on front & rear axlesSRear and lateral camera with cab screenSRear bumperORight side bumperOSteel Protection Guards on all working and road lightsSSystem with attachments recognition (E-reco)S	,	S
Loose wheel nut indicatorsSMarking - Warning & Danger decalsSMining protection grids: right, left and back windowsONegative brakes on front & rear axlesSRear and lateral camera with cab screenSRear bumperORight side bumperOSteel Protection Guards on all working and road lightsSSystem with attachments recognition (E-reco)S	· ·	S
Marking - Warning & Danger decals S Mining protection grids: right, left and back windows O Negative brakes on front & rear axles S Rear and lateral camera with cab screen S Rear bumper O Right side bumper O Steel Protection Guards on all working and road lights S System with attachments recognition (E-reco) S	5 , 1	
Mining protection grids: right, left and back windows 0 Negative brakes on front & rear axles S Rear and lateral camera with cab screen S Rear bumper 0 Right side bumper 0 Steel Protection Guards on all working and road lights S System with attachments recognition (E-reco) S	Marking - Warning & Danger decals	S
Negative brakes on front & rear axles S Rear and lateral camera with cab screen S Rear bumper O Right side bumper O Steel Protection Guards on all working and road lights S System with attachments recognition (E-reco) S		0
Rear and lateral camera with cab screenSRear bumperORight side bumperOSteel Protection Guards on all working and road lightsSSystem with attachments recognition (E-reco)S		S
Rear bumper 0 Right side bumper 0 Steel Protection Guards on all working and road lights S System with attachments recognition (E-reco) S	5	S
Right side bumper 0 Steel Protection Guards on all working and road lights S System with attachments recognition (E-reco) S	Rear bumper	0
Steel Protection Guards on all working and road lights S System with attachments recognition (E-reco) S	•	0
System with attachments recognition (E-reco) S	5	

Equipment

Standard
"Guardian Angel" System Level 1
360° visibility safety system
Battery + Starter Isolators + Jump Start Receptacle
Boom cylinder lock
Brake Lights ON When Park Brake ON
Cabin first step at 400 mm
Camera in boom head with screen in cab
Clamp predisposition (controls from cabin)
Emergency steering
Emergency stop: 1 in cab, 2 on external
Exhaust fume purification system
Extinguisher brackets (x3)
Flat Led Rotating Beacon
Fuse board protection - MHT's
High visibility reflective strips
Hydraulic hose sleeve burst protection
LED Flashing Lights On Cabin (Marker Lights)
LED tramming lights
LED work lights - On the top of the boom (fixed part) (x2)
LED working lights on cab (x4 : 2 front + 2 rear)
Loose wheel nut indicators
Marking - Warning & Danger decals
Negative brakes on front & rear axles
Radiator safety cap
Rear and lateral camera with cab screen
Roof and Windshield Guard
Steel Protection Guards on all working and road lights
System with attachments recognition (E-reco)
Wheel chocks
Working platform predisposition with remote control

Optional

Automatic greasing system (AGS) - Chassis + boom
Electromagnetic braking system TELMA
Emergency stop by safety valve
Engine compartment fire prevention kit
Fast fuel filling system
Fire suppression system
Mining protection grids: right, left and back windows
Rear bumper
Right side bumper
Steel mudguards



Head Office B.P. 249 - 430 rue de l'Aubinière 44150 Ancenis Cedex - France Tel: +33 (0)2 40 09 10 11 - Fax: +33 (0)2 40 09 10 97 www.manitou.com



This publication provides a description of the configuration versions and options for Manitou products, which may differ for equipment. The equipment presented in this brochure may be part of a series, as an option, or it may not be available, depending on the versions. Manitou reserves the right, at any time and without notice, to amend the specifications described and represented. The specifications provided do not bind the manufacturer. For more details, please contact your Manitou agent. This is not a contractually binding document. The presentation of the products is not contractually binding. List of specifications non-exhaustive. The logos as well as the visual identity of the company are owned by Manitou and cannot be used without authorisation. All rights reserved. The photos and diagrams contained in this brochure are only provided for consultation and information purposes.

MANITOU BF SA - Limited company with board of directors - Share capital: 39,668,399 euros - 857 802 508 RCS Nantes